



## Super Lynk®



*Super Lynk is a panel-to-foundation connection system that eliminates the need for epoxy, grout and field welds*



### Heightened Performance and Reduced Visibility

Super Lynk is a fast, strong and discrete way to permanently connect concrete panels to footings. It requires only a single bolt to make the connection – no welds, grout or epoxy.

#### Features:


- **Saves time and money:** The single-bolt connection is simple and quick to install while eliminating the need for epoxy, grout and in-field welding, saving you time and money.
- **Improved performance:** The engineered, patent-pending connection system has been developed by Meadow Burke's team of Tilt-Up experts to meet ACI 318-14 16.2.4.3 (b).
- **Improved aesthetics:** With a profile less than 2.5", the Super Lynk is discrete relative to alternative connection systems and can easily be concealed by normal backfill and landscaping.

\* Void former shown in yellow for marketing purposes only.  
Actual void former is concrete gray.

Call to learn more about  
the Super Lynk

877.518.7665

## Super Lynk Installation



### STEP 1 – Attach to the form

- Attach the anchor to the bottom corner of the concrete panel form with the use of screws or nails through the side tabs of the void and into the wood form.
- Use a plastic 1 1/2" MB Tuff Chair to support the weight of the anchor and hold embossed side of the void flat to the casting surface.



### STEP 2 – Remove Void Cover

- Following panel erection, remove the void cover, revealing the Pivot Link.



### STEP 3 – Access Pivot Link

- Rotate the Pivot Link until it protrudes outside of the panel face.



### STEP 4 – Drill the bolt hole

- Mark the location for the drill hole beneath the eye of the Pivot Link.
- Mark anchor location and drill a 20mm diameter straight hole at least 10" deep. Clean as much from the hole as possible by periodically lifting bit while drilling. The added depth is required to accommodate dust from drilling and thread cutting.



### STEP 5 – Bolt into the foundation

- Using a large 3/4" impact wrench with a 30mm socket, drive the MB 10" Brace Bolt into the drilled hole until the bolt head is flush to the link. No torque wrench is required to achieve a full-strength connection.



### STEP 6 – Panel is connected to the foundation